



TWO-WAY FM LED AUTOMATIC/MANUAL
TRANSMISSION REMOTE STARTER

AS-3372TW-FM

Installation Guide

Notice

The manufacturer will accept no responsibility for any electrical damage resulting from improper installation of the product, be that either damage to the vehicle itself or to the unit. This unit must be installed by a certified technician using all safety devices supplied. Please note that this guide has been written for properly trained Autostart technicians: a certain level of skills and knowledge is therefore assumed. Please review the installation guide carefully before beginning any work.

Warning

Before installing the unit, if installing on a vehicle with a **manual** transmission, test that the OEM Door Switch contacts of the vehicle work well, and that the Parking Brake system operates properly. If installing on a vehicle with an **automatic** transmission, test that the vehicle does not start when the gearshift lever is in the "Drive" position. If it starts in gear, reset the remote starter to manual transmission.

Table of Contents

Introduction	2	Lock Pulse Duration.....	22
Included in the Kit	3	Flashing LED.....	23
Installation Tools	3	Safe Start	23
Installation Points to Remember	3	Engine Run Time	23
Installation Order	5	Idle Mode.....	23
A basic introduction to the Relay	7	Turbo Mode.....	24
Harness Description	11	Cold Weather Mode	24
6-pin Main Ignition Harness (a.k.a. The Primary harness).....	11	Valet Mode	25
5-pin Secondary Harness (a.k.a. the secondary harness).....	12	"Home Valet™" Mode	26
12-pin Accessories Harness	12	Panic Mode	26
3-pin Harness.....	14	The AUX 1 / 2 nd Unlock	27
Additional Ports	14	The AUX 2 Timed Output.....	27
Entering Programming Mode	15	The AUX 3 / Trunk or Sunroof Output	27
The Programming Assistance Button (a.k.a. PAB)	15	Programmable External Trigger.....	27
Manual or Automatic Transmission	15	Multi-Level Features (<i>default state</i>)	27
Transmitter Programming Procedure	16	OEM-Style Alarm	29
Entering Programming Options	16	Ready Mode Option	29
Programming Options	17	Bypass.....	29
Virtual Tach System	18	Vehicle Status Request.....	30
Optional Time Delay Adjustment in Virtual Tach System	18	Status Request When the Engine IS NOT Running.....	30
Multi-speed Tach Programming	19	Ready Mode Status Request.....	30
Other Features of the Module	19	Status Request When the Engine is Running	31
Tach jumper settings.....	19	Multi-car Operation.....	31
Clutch Bypass	20	Horn Honk Timing	32
Installation-programmable Features	21	Resetting the module to default features	32
Ignition-controlled Door Locks	21	Closing Up	32
Secure Lock	21	Testing	32
Starter Kill Arming Mode	22	Troubleshooting Poor Transmitting Range	33
		Diagnostics – Parking Light Flash Table	34
		Troubleshooting Q & A	35

Introduction

This Guide contains all information pertinent to the installation. Most (if not all) features are grouped in the User Guide. Therefore, should you need information on a feature, please refer to the User Guide.

Included in the Kit

Before beginning the installation, please review the Installation Guide —particularly the Wiring Diagram and the Programming Options.

Note: It is very important that you familiarize yourself with the programming and operation of the system, even if you have already installed a similar system in the past.

There are many great new features you may overlook if you do not read the Guide—you would not maximize the potential of the unit. Prior to the installation, make sure that all the hardware components required to install the system are in the box.

The following is a list of components included in the kit:

- 1 – Control Unit
- 2 – Five-button transmitters
- 1 – Antenna interconnect cable
- 1 – 6-pin main ignition harness
- 1 – 5-pin secondary harness
- 1 – 3-pin secondary harness
- 1 – 12-pin accessories harness
- 1 – Hood pin-switch
- 1 – Warning label
- 1 – User Guide
- 1 – Quick Installation Guide

Please note: the plug-in valet button is not included with this model.

Installation Tools

Here is a list of basic tools and supplies you will need to test and install safely:

- Digital multimeter (DMM), neon 'trouble' light that is carpet safe, fender protector, carpet protector
- Soldering iron, solder, electrical tape, wire tie straps, split loom, diodes, resistors, relays
- Wire cutters, wire strippers, wire crimpers, needle nose pliers
- Sharp knife, panel poppers, various screw drivers
- Socket set, wrench set, drill with drill bits, plastic fishing tool (for fishing wires through the firewall)

Installation Points to Remember

- ◆ On vehicles with a manual transmission, **always** ensure that all doors will get the unit out of ready mode. Switch the wire used so that it is triggered by all Doors.
- ◆ Make sure that the Parking brake and Door switch contacts work properly.
- ◆ When working on a vehicle, always leave a window open.
- ◆ **Never** leave the keys in the car. Leave them on a workbench with a window rolled down.
- ◆ If possible, remove courtesy light fuse to prevent battery drain.
- ◆ **The Programming Assistance Button (a.k.a. PAB):** The PAB is mounted on the side of the unit. This push button mimics the hood-pin switch in order to avoid having to get out of the vehicle and pressing the hood-pin switch. **The PAB will work only when the hood is up.**
- ◆ Inspect vehicle for any body damage or electrical problems.
- ◆ **Always solder and tape all connections.**
- ◆ Keep the transceiver away from other types of antennas (GPS/OnStar®).
- ◆ Never install the control unit where it could interfere with normal operation or obstruct service technicians.
- ◆ Always use a grommet when running wires into the engine compartment.
- ◆ Never run wires through bare or sharp metal.
- ◆ Do not disconnect the battery on vehicles equipped with air bags and anti-theft radios.
- ◆ Never ground the control unit to the steering column.
- ◆ Make sure that all the switches and controls operate properly.
- ◆ Verify that the vehicle starts and idles properly.
- ◆ Make sure that all safety equipment is installed: the valet button (if installed), the hood switch, and the warning label.

◆ When wiring in parallel, make sure to isolate each connection with a diode in order to avoid feedback and possible damage.

Examples:

Wiring a clutch bypass and a transponder module to the ground out when running wire: At the junction point, where Ground Out when running “splits” and goes to each device, a diode is inserted on each of those lines.

Multiple or separate door pin connections:

When joining all door pins together to the door pin input wire of the module, each wire must be isolated with a diode to prevent feedback.

N.B.: *The above examples reflect common situations where diodes are used to isolate. Please note that there are numerous other scenarios where diode isolation is required.*

◆ Always make sure that any external relays or modules added to the Remote Starter module are properly fused and diode isolated.

◆ When testing the Shock Sensor, never test on glass with an opened hand, and never hit glass hard enough as to break it. When testing on metal or plastic, make sure the testing does not result in damage to the vehicle (i.e.: dents, broken glass, damaged trims, etc.).

◆ Vehicles equipped with daytime running lights may not allow the installer to view certain programming results since the daytime running lights do not go out (**Note:** The Parking Light output relay in the module gives two “clicks” per flash, 1 “click” for ON and 1 “click” for OFF).

◆ Parking Light flashes referred to in this manual refer to the Parking Light output of the module and not that of the vehicle.

Installation Order

The following is a suggested order for the Installation procedure. It is intended as a guide for novices, to help make the process of installing a remote starter module easier. Time is wasted by rewiring the module when mistakes are made. Also, the neatness of the installation is lessened every time the module is taken down and the wiring is "corrected". A messy installation is harder to trouble shoot if there are problems later on. The actual "how to install" is not covered by this list; the order of the installation process is the focus.

- Before you get started, make sure the vehicle starts and idles properly with the Ignition key, and that the electrical system is not compromised in any way.
- After deciding what options are to be added to the basic installation, you can start by looking for the wires that will be needed.
- Remember to be careful when removing the panels that are covering the wires you are searching for.
- Once all of the wires have been found, they should be tested to verify that they are the correct ones you will need for the installation.
- When all the wires pass the test, they can be stripped to expose the wire (over one inch of plastic should be removed).
- It is always better to strip more than you need. A common way cold solder joints happen is when not enough plastic is stripped off the vehicle's wire, so during the soldering process the plastic from the wire melts and flows into the connection instead of the solder.
- Decide where the module is going to be mounted. It is ALWAYS mounted inside the passenger compartment, and never in the engine bay. Under the driver's side of the dash there is usually enough room for the module to fit. Once the location has been decided, proceed to the next step.
- Mount the antenna and run the cable to the location where the module is going to be mounted. The antenna will get the best range when it is high up in the vehicle, and not obstructed by metal. The most common choice is the center of the windshield at the top, behind the rear view mirror, and at least one inch below the tint strip. Another location should be used if there is another antenna in this location, compass, or other device that may interfere with the range of the start module.
- Mount the Valet switch and LED (if applicable). Make sure they are close enough to the selected module mounting location so they will plug in when the module is mounted. If the wires are too short, they will have to be extended.
- In the engine compartment, mount the hood pin, in a suitable location. Search along the firewall for an OEM grommet you run the wires through. If you cannot find an OEM grommet to use, you will have to drill a hole. The hole must be big enough for all of your wires to fit through. To be safe drill the hole out a little bigger so the wires will not get squished. We recommend using an aftermarket grommet whenever you drill a hole through the firewall. This will protect the wires from rubbing against the bare metal and possibly shorting out. If you are installing an alarm / starter combo module, mount the siren in the engine compartment at this time.
- The next step is to pre-wire the module. This is done on your work bench, and not in the vehicle. Connect any external modules and relays that may be needed for you install. Tape or tie-trap wires that are going to be routed to the same areas of the vehicle. This will keep things neat

when the module is in the vehicle. The fuses on the power wires should be removed during the pre-wire stage. The fuses will not be put back in until the powering stage of the installation.

- Once the pre-wiring is finished, the module can be brought into the vehicle. Before the module is mounted, connect the antenna, the valet switch, shock sensor (if applicable) and LED to the module. With everything connected to the module, it can now be mounted in the vehicle. Use tie-straps to secure it to the vehicle. Make sure the module and harnessing do not interfere with any moving parts, and do not obstruct access to diagnostic ports, or fuse boxes. It should be up in the dash, high enough that it won't get kicked by accident.
- Once the module is secured, route the wires to the previously stripped wires they correspond to (leave the engine compartment wires for last). Tie strap them up as you go, so they do not interfere with anything else.
- When all of the passenger compartment wires are ran to their locations, you can route the engine compartment wires through the firewall.
- With the engine compartment wires out the way, you can begin making the connections in the passenger compartment. Strip about an inch of wire past where the connection is going to be made. This extra bit of wire is wrapped around the exposed OEM wire to secure in place while you are soldering.
- When all of the wires have been connected, solder the connections. When the solder has cooled, the connections are then individually taped up, to isolate them.
- Return to the engine bay and route the start module wires to their corresponding connections.
- Solder the engine compartment wire once the connections are made. When the solder has cooled, the connections are then individually taped up, to isolate them.
- Use your DMM to verify that your ground location is good before grounding the module.
- The last step before programming is to power up the module. Replace the power fuses on the power wire fuse holders. The module will flash the Park lights twice to confirm the power-up.
- If you are installing an alarm / starter combo module, the siren will be sounding at this point. Place the module into Valet mode to silence the siren. Take the module out of valet mode to continue the programming (**note:** the module default programming is passive arming; after exiting valet mode, the alarm will start the countdown for passive arming. You have 30 seconds to begin the remote control programming procedure, before the module rearms).
 - Program the remote control
 - Program the tach signal
 - Change the programming of the options, if necessary
 - Test the module's operations
 - If all of the testing is successful, the installation is completed and the vehicle can be put back together.

A basic introduction to the Relay

What is a relay?

A device that responds to a small current or voltage change by activating switches or other devices in an electric circuit. An electromagnetic switch, remote-controlled switch, a switching device.

Why are Relays used?

Relays can have several purposes in remote car starter installations. They are used mainly for isolation, inversion, interruption, strengthening current, and for **powering multiple wires from one source SAFELY**.

How does it work?

The basic relay consists of a coil and a set of contacts. The most common relay mechanism is electromagnetic. When voltage is applied to the coil, current passes through the wire and creates a magnetic field. This magnetic field pulls the contacts together and holds them there until the current flow in the coil has stopped.

Relays come in all varieties and types, but for the applications that concern us, we will concentrate on the **Single Pole Double Throw (SPDT) 12 Volts relay**.

Naming Convention:

Usually the relay's manufacturer will include an electrical diagram on the relay displaying the role of each terminal and how they interact with each other. These terminal numbers are standard, and can be used with any SPDT relay.

85 & 86: The Coil. These inputs energize the coil when one is +12 Volts, and the other is Negative. They are usually non-polarized, so it does not matter which one is positive (+) or negative (-).

87: Normally Open (N/O). When the coil is energized, 87 is connected to 30.

87A: Normally Closed (N/C). When the coil is at rest, 87A is connected to 30.

30: Common. When the relay is at rest, 30 is connected to 87A. When the coil is energized, it is then moved and makes contact with 87 (**note:** in a SPDT relay, 30 can never be connected to 87 and 87A at the same time; 30 is connected to **either** 87 OR 87A)

What happens:

When there is no voltage across the COIL (terminals 85 and 86), the relay's movable contact ARM (connected to terminal 30) is held, by SPRING tension, against terminal 87a (normally closed circuit).

When 12 volts is applied to the COIL (terminals 85 and 86), the ARM (connected to terminal 30) is pulled in by the electromagnet (COIL) so that it physically connects to terminal 87 (normally open circuit)

Remember, there is no polarity on a relay's coil. This means that you may apply positive from the battery to either terminal 85 **OR** 86, and then Ground the OTHER terminal to activate the relay. In other words, you may use either a positive or negative trigger to energize the relay.

Keep in mind that when the relay is energized, if the positive **OR** the ground connection on the coil is broken, the ARM switches the connection between 30 back from 87 to 87a.

Quenching Diodes:

It was said earlier that you energize a relay by applying positive from the battery to either 85 OR 86 and grounding the other terminal. This is not absolutely true: some relays are "polarized" if they have a quenching/suppression diode (a diode installed between the coil terminals 85 and 86, could be internal or external). To activate the coil on this type of relay, make sure that the +12 Volts trigger is on the same terminal of the relay as the Cathode (- or striped side) of the

quenching/suppression diode, and that the Negative trigger is on the same terminal of the relay as the Anode (+ or non-stripped side) of the quenching/ suppression diode.

When a relay's coil is energized, a magnetic field is created and energy is stored in the coil. When power is removed from the coil, the magnetic field collapses. This causes a Reverse Voltage to be generated and can sometimes reach 200 volts. A quenching diode absorbs this reverse voltage spike.

A closer look at a relay:

Now that you know what the main inscriptions are on the relay, take a look on the side, and you will see another inscription: i.e. **(12 VDV, 40/ 30 A)**

12 VDC: This indicates the coil voltage rating. For an Automotive relay, it's usually 12 Volts DC.

40/ 30 A: This indicates the current carrying capability of the contacts 30, 87, & 87A.

40: Indicates that the normally closed circuit (30 and 87a) can safely handle a maximum of 40 amps of current.

30: Indicates that the normally open circuit (30 and 87) can safely handle a maximum of 30 amps of current.

Examples: The following examples demonstrate some of the most common uses for relays: isolation, inversion, interruption, strengthening current, and for powering multiple wires from one source SAFELY.

Powering multiple wires from one source safely:

Example: Powering a second Ignition

Problem: You need to power Multiple Ignition wires to remote start the vehicle, but your module only has one Ignition output available.

Solution: You will need to add a second ignition relay to power the second ignition wire. **(Jumping Ignition 1 to Ignition 2 is NEVER recommended. Always use a relay. The vehicle circuits are isolated for a reason; the wiring of the remote star module should reflect this.)**

The relay connections:

85: Connects in parallel to the Ignition 1 output from the remote start module. This becomes the positive side of the coil.

86: Connects to the **Ground Out when Running** wire from the remote start module. This becomes the negative side of the coil.

87: Connected to a Fused +12 Volts source that is capable of supplying power for the vehicle's second ignition wire. This becomes the source of power for the 2nd ignition wire.

87A: No connection. This terminal is not used in this application.

30: **Connects to the vehicle's second ignition wire.** This becomes the output of the 2nd ignition relay.

Comments: The relay is only energized when the vehicle is running by remote start. When started with the Key, the relay is not energized and the integrity of the stock system has been preserved.

Isolation:

Example: Isolating a Parking light output

Problem: Some vehicle circuits need to be isolated from feedback. In some cases, when a vehicle is remote started, feedback occurs on a circuit and powers another device or switch that was not intended to be powered during the remote starts.

The following example will be a Positive (+) Parking Light circuit that feeds back and activates the windshield wipers during remote starts.

Solution: When power is applied to the OEM Parking light wire, it back feeds through the parking light switch and activates the wipers. Where the connection was made from the start modules' Parking light output and the vehicle's parking light circuit, the OEM parking light wire is cut to isolate the parking light switch and the actual parking lights. A Relay is added to the parking light circuit so that power from the remote start module is only sent to the parking lights and not the parking light switch.

The relay connections:

85: Connects to the +12 Volt Parking light output from the remote start module. This becomes the positive side of the coil.

86: Connects to a Negative source, i.e. the spot where the remote start module is grounded. This becomes the negative side of the coil.

87: Connects to the +12 Volt Parking light output from the remote start module. This becomes the power supply for the vehicle's parking lights. The OEM parking light wire is cut. The side that is still connected to the switch becomes the "Switch Side". The side that is still connected to the Parking lights becomes "Parking Lights Side".

87A: Connects to the "Switch Side" of the cut OEM parking light wire.

30: Connects to the "Parking Light Side" of the cut OEM parking light wire.

Comments: When the relay is at rest, the OEM Parking light wire is connected (through 87A & 30) and allowed to operate normally. When the remote start module powers the Parking lights, the OEM parking light wire is opened, and power from the remote start module is sent only to the actual Parking Lights (from 87 through 30).

Inversion:

Example: Activating a Positive Trunk release switch

Problem: The vehicle's power trunk release switch is activated by a positive (+) pulse, and the remote start module's Trunk output is negative (-).

Solution: A relay is used to invert the negative signal from the start module to a positive signal before it is sent to the OEM switch.

The relay connections:

85: Connects to the start module's Trunk release output wire. This becomes the negative side of the coil.

86: Connects to a fused +12 Volts source. This becomes the positive side of the coil.

87: Connects to a fused +12 Volts source. This becomes the supply for the positive trunk release.

87A: No connection. This terminal is not used in this application.

30: Connects to the OEM trunk wire in the vehicle.

Comments: At rest, the trunk switch is allowed to operate normally. When the Trunk button on the remote is pressed, the negative Trunk output from the remote start module triggers the relay. When

the relay is activated, +12 volts from 87 is sent through 30, and the OEM trunk switch is activated, by the positive pulse.

Interruption:

Example: Creating a Starter Kill relay to prevent unauthorized starting of the vehicle.

Problem: The OEM starter circuit needs to be disabled only when theft is attempted.

Solution: A relay is used to interrupt the OEM starter wire. There is an output on the remote start module especially for this purpose (Starter Kill output).

The relay connections:

85: Connects to the Starter Kill output wire from the remote start module. This becomes the negative trigger for the coil.

86: Connects to the vehicle's Ignition wire. This becomes the positive trigger for the coil.

87: No connection. This terminal is not used in this application. The vehicle's OEM start wire is cut. The side of the wire that is still connected to the Ignition switch becomes the "Key Side" of the starter wire. The side of the wire that is still connected to the starter motor becomes the "Starter Side" of the starter wire.

87A: Connects to the "Key Side" of the cut OEM starter wire.

30: Connects to the "Starter Side" of the cut OEM start wire.

Comments: At rest the relay is not active, and +12 volts on the starter wire passes through the relay (through 87A & 30) normally. The Starter Kill output wire on the remote start module is activated when the **LOCK** button is pressed on the remote control. When a theft attempt happens, and the thief powers the Ignition circuit (to hot wire the vehicle), and the Starter Kill was **ARMED** (by the **LOCK** button on the remote), the starter kill relay activates. The OEM start wire is now open, (does not make connection) because 30 is no longer connected to 87A, and the vehicle is unable to start.

Strengthening current:

Example: Strengthening an output

Problem: A vehicle has a negative (-) trigger Trunk release wire. The module has a negative Trunk release output wire. The remote start module is unable to supply the necessary current to activate the vehicle's Trunk release wire.

Solution: A Relay is used to provide the necessary negative current to activate the vehicle's Trunk release wire.

The relay connections:

85: Connects to the start module's Trunk release wire output. This becomes the Negative trigger for the coil.

86: Connects to a fused +12 Volt source.

87: Connects to a Negative source, i.e. the spot where the remote start module is grounded. This becomes the supply for activating the vehicle's Trunk release wire.

87A: No connection. This terminal is not used in this application.

30: Connects to the vehicle's Trunk release wire.

Comments: At rest the relay is not active and the vehicle's Trunk release switch is allowed to operate normally. When the Trunk release button is pressed on the remote control, the start

module's Trunk release output activates the relay. The ground signal is sent from 87 through 30 to the vehicle's Trunk release wire activating the switch and opening the trunk.

Harness Description

6-pin Main Ignition Harness (a.k.a. The Primary harness)

The two Red wires are the power inputs for the module; the other wires are for recreating the actions of the Ignition switch during remote starts. On most vehicles these wires are connected at the vehicle's Ignition switch.

Wire	Description
1 RED (+) 12 V Battery	Connect to the largest 12 V supply wire at the Ignition harness. Ensure that the OEM power wire is fused for more than 30 A. NOTE: Certain new vehicles have no suitable 12 volts source at the IGNITION switch (the 12 Volt wire is too small to supply the necessary current). In this case, the fuse box, or the B+ connection on the battery is recommended. If wires need to be extended, you must protect them with additional fuses connected at the entry source.
2 VIOLET (+) 30 A starter output	Connect to the Starter wire of the vehicle (at the IGNITION switch). The source wire should have +12 V with the Ignition Key in the Crank position only.
3 RED (+) 12 V Battery	Connect to the largest 12 V supply wire at the Ignition harness. Ensure that the OEM power wire is fused for more than 30 A. NOTE: Certain new vehicles have no suitable 12 volts source at the IGNITION switch (the 12 Volt wire is too small to supply the necessary current). In this case, the fuse box, or the B+ connection on the battery is recommended. If wires need to be extended, you must protect them with additional fuses connected at the entry source.
4 PINK (+) 30 A ignition output	Connect to Ignition wire of the vehicle. The source wire should have +12 V with the Ignition Key in the Ignition On (Run) and Crank positions. Warning: some vehicles have more than one IGN wire at the IGNITION switch for powering the heater blower motor. Use the 5th relay (pin F) and extra relays to power up any extra IGN. wires if necessary. DO NOT JUMP WIRES at the IGNITION switch, this will compromise the OEM electrical system. If wires need to be extended, you must protect them with additional fuses connected at the entry source.
5 ORANGE (+) 30 A Accessories output	This wire is for powering the heater blower motor. It is usually classified as an Acc. (no power in the crank position.) if it tests as an IGNITION (power in the crank pos.) then power it as an IGNITION (5th relay, or extra relay). Warning: some vehicles have more than one ACC wire at the IGNITION switch for powering the heater blower motor. Use the 5th relay (pin F) and extra relays to power up any extra ACC. wires if necessary. DO NOT JUMP WIRES at the IGNITION switch, this will compromise the OEM electrical system.
6 PINK/WHITE (+) 30 A 5 th relay output	This high-current output can be used to power a 2 nd IGNITION or a 2 nd ACCESSORY or a 2 nd STARTER WIRE . See jumper settings on page 19 for correct output. Additional IGNITIONS, ACCESSORIES, or STARTER WIRES must use external relays. DO NOT JUMP WIRES at the IGNITION switch, this will compromise the OEM electrical system.

5-pin Secondary Harness (a.k.a. the secondary harness)

This harness has the remaining wires used in basic remote starter installations, positive parking light output, the safety shut down inputs, and the ground wire for the module.

Wire		Description
1	BLACK (-) Chassis ground input	This wire must be connected to bare, unpainted metal (the Chassis or true Body ground).
2	VIOLET/WHITE (AC) Tachometer input	This wire tells the module if the Engine is running or not. It requires at least 1.8 volts (AC) and 1.5 Hz (or faster) at idle. Common Tach references are: the negative side of an injector, the negative side of an Ignition Coil, Camshaft sensor, Crankshaft sensor or the Engine Control Module (ECM). NOTE: A Tach signal that is too low will cause the module to "over crank" and a Tach signal that is too high will cause the module to "under crank".
3	GRAY (-) Hood switch input	For safety reasons, this wire must be connected to the hood pin provided in the box or to the OE hood pin. This input will disable or shut down the Remote Starter when the hood is opened. It can also be used for programming purposes.
4	BROWN (+) brake switch input	This wire must be connected to the brake Light switch of the vehicle. The wire should be +12 V only while the brake pedal is pressed. This input will shut down the Remote Starter if the brake pedal is pressed. It is also used for programming and therefore it is essential that it is installed.
5	WHITE (+) 12 V Parking Light output	This wire provides a +12 V output (15 A max.) and must be connected to the Parking Light wire that tests +12 V when the Parking lights are ON. Note: Ensure that the voltage does not vary when the dimmer control switch is turned up or down. If this is the case, it is not the right wire. There is also a negative Parking Light output on the 3-pin side connector. Only one of these two different outputs needs to be connected.

12-pin Accessories Harness

This harness has the remaining wires used in some remote starter installations as well as the optional user convenience outputs.

Wire		Description
1	RED/WHITE (-) Trunk or AUX 3 output	500 mA negative output. This can be used to control trunk release (1-sec. pulse) or to operate as a constant output as long as the TRUNK button is held pressed (for Sunroof or Window close).
2	LIGHT GREEN (-) Lock	Programmable 500 mA 1/10-sec., 7/10-sec. or 4-sec. negative output.
3	BLUE (-) Unlock	Programmable 500mA 1/10-sec., 7/10-sec., 4-sec. or 1/4-sec. double-pulse negative output.
4	LIGHT GREEN/WHITE (-) Arm	Max 500 mA negative output when the doors are locked by remote control. This wire will provide a negative output 1/4 sec. before the lock pulse, and go off 1/8 sec after it. Note: The system will also give a rearm pulse on this wire after remote-start shutdown.
5	LIGHT GREEN/BLACK (-) Disarm	Max 500 mA 1-sec. negative pulse when the Doors are unlocked by remote control. Connect to the OEM Disarm wire of the vehicle. Note: The system will also give a disarm pulse on this wire before remote starts.

6	VIOLET (+) Door pin input	<p>This input should be used in vehicles that use a positive-switching Dome Light circuit. Connect to a Door trigger wire testing +12 V with a Door open.</p> <p>CAUTION! You can only use a negative or a positive connection. In other words, only the NEGATIVE DOOR INPUT or the POSITIVE DOOR INPUT wire is connected. It is essential that the Module be connected in such a way as to allow each Door to turn off Ready Mode: the driver-side Door Pin does not constitute by itself a sufficient connection.</p>
7	ORANGE (-) Starter Kill (armed output)	<p>The unit is equipped with a selectable passive- or active-arming Starter Kill circuit that will immobilize the vehicle when the system is armed. This wire will provide a constant 500-mA negative output when the system is armed (locked by remote) or if remote started. This wire should be connected to a Single Pole Double-Throw Relay (This wire will connect to pin 85, on the Relay, and pin 86 will be connected to the Ignition wire).</p> <p>A second benefit of the Starter Kill is the Anti-Grind feature. When the vehicle has been remote started the Anti-Grind prevents the starter motor from re-engaging when the ignition key is inserted in the Ignition switch and accidentally turned to the CRANK position (The Starter Kill output becomes active during remote starts).</p>
8	BLACK/WHITE (-) Parking brake Input	<p>Connect to the negative Parking brake Indicator Light wire of the vehicle. This wire is found at the parking brake lever itself.</p> <p>Note: The wire should test ground when the Parking brake is engaged.</p>
9	WHITE/BLUE (-) External Trigger input	<p>The External Trigger wire can be used for remote-starting the vehicle with an external device. When the vehicle is running, triggering this input will activate Idle Mode. The External Trigger wire can also be used to operate as a negative trigger with the Trunk pin-switch or the Key Sense wire (by default).</p> <p>Option 1 Connects to (-) Negative Trunk pin. When this wire is programmed for trunk pin, pressing TRUNK will activate a 1-second disarm output. If ground (-) is detected on the trunk pin (the Trunk has been opened), an ARM pulse will be sent 5 seconds after the Trunk is closed. An ARM pulse will be sent 4 seconds after the TRUNK button is pressed if the Trunk pin state is unchanged (The Trunk was unopened). Disarm is sent only if the system was previously locked and armed. If secure lock is enabled, unlock pulse(s) will be sent with disarm, a lock pulse and a rearm pulse will be sent when the TRUNK is closed or if the TRUNK was left closed.</p> <p>Option 2 (Default: Key Sense (-) Input): Connects to OEM Key Sense Wire. When the Key is detected in the Ignition switch (Ground (-) signal on the OEM Key Sense Wire) the Starter Kill will not ARM even when it is set to Passive Mode. If Secure Lock is programmed, LOCK and ARM will not be activated while the Key Sense input is active ("active" meaning there is a key in the Ignition barrel).</p> <p>Option 3 (Engine Start/Stop): The first (-) pulse on this input will start the Engine, the second (-) pulse on this input will stop the Engine. It is also used to activate ready mode.</p> <p>Option 4 (Pager): Enables the pager port located at the back of the remote starter.</p>
10	BLUE/BLACK (-) Ground out when running	<p>500 mA constant negative output when running.</p> <p>This output becomes active before remote Ignition On, and shuts off when the module is shut down.</p> <p>Note: If multiple relays or modules are connected to the ground out wire, make sure that each one of them is diode-isolated from the others. Otherwise feedback effects may occur, which could damage the vehicle and/or the modules, relays, and bypass modules.</p>
11	GREEN (-) Door Input	<p>This input should be used in vehicles using a negative-switching Dome Light circuit. Connect to the Door trigger wire that tests ground with a Door open.</p> <p>It should be noted that the installer should use either the positive or the negative Door input, and never use both of them simultaneously.</p>
12	GRAY/BLACK (+) Glow-plug input	<p>This positive input will monitor the Glow Plug Light in Diesel Mode: it will wait until the Glow Plug Light goes out to crank the Engine. Connect to the side of the Glow Plug Light that becomes positive when the Light is on.</p> <p>Note: In Diesel Mode there is an 18-sec. crank timing delay (or approximately 25-sec. if the run time is set to 30 min.): if the Glow Plug Light is still on after the delay expires, the module will proceed to start the Engine.</p> <p>(Also known as the "wait-to-start light".) The purpose of the Glow-plug circuit on diesel</p>

		<p>vehicles is to pre-heat the Combustion Chamber before the vehicle is started.</p> <p>When a Remote Starter is installed on a diesel vehicle, the Glow- plug section of the Ignition circuit must be activated and allowed to operate before the vehicle is remote-started. For that purpose, the Glow-plug input wire of the module must be connected to the Glow-plug indicator light of the vehicle. The module will only accept positive Glow-plug input signals, if the signal is negative, use a relay to invert its polarity. A diode must be added between the negative Glow-plug trigger on the relay and the negative Glow-plug wire of the car. This is to prevent feedback effects on the Glow-plug indicator light on the instrument cluster: the light on the dash would come on because of the feedback, even though the circuit is off.</p> <p>When the user remote-starts the vehicle:</p> <p>The module will power up the Ignition circuit and wait to engage the Starter Motor while the Glow-plug indicator light is still on.</p> <p>The module will engage the Starter Motor as soon as the Glow-plug light (+) goes out. Minimum waiting time is 3 seconds.</p> <p>Maximum waiting time is 30 seconds (approximately).</p> <p>If no Glow-plug wire is found on the vehicle, the Glow-plug input on the module may be "timed out". The module will power up the Ignition and Glow-plug circuits and simply wait for the time-out before starting.</p> <p>Keeping the Glow-plug input wire of the module unconnected will hold the ignition ON for the preprogrammed delay.</p> <p>Please program the tach before connecting the glow-plug input to the vehicle.</p>
--	--	---

3-pin Harness

	Wire	Description
1	VIOLET/BLACK (-) AUX 2 Output	500 mA negative output. Can be programmed for one of the following four options : <ol style="list-style-type: none"> 1. Constant while the LOCK and UNLOCK buttons are pressed, + 1 sec. after the buttons are released. 2. Pressing the LOCK + UNLOCK buttons simultaneously will toggle the AUX 2 output ON/OFF for up to 30 sec. 3. Pressing the LOCK + UNLOCK buttons simultaneously will toggle the AUX 2 output ON/OFF for up to 4 min. (active only when under remote run). 4. Priority door access. Produces a (-) pulse on the 2nd press of the UNLOCK button.
2	LIGHT BLUE (-) AUX 1 Output	500 mA negative output. Can be programmed for one of the following three options : <ol style="list-style-type: none"> 1. Horn confirmation on the 2nd press of the LOCK button. 2. Priority door access. Produces a (-) pulse on the 2nd press of the UNLOCK button. 3. Horn confirmation on 1st press of the LOCK button.
3	WHITE/BLACK (-) Parking lights output	500 mA negative Parking Light output Note: Ensure that the voltage does not vary when the dimmer control switch is turned up or down. If this is the case, it is not the right wire. There is also a positive Parking Light output. Only one of these two different outputs needs to be connected.

Additional Ports

	Port	Description
1	Temperature Sensor (Optional)	N/A
2	RS-232 Port	For D2D connection; is used to interface bypasses and door locks convenience module (check bypass list for compatibility and functionalities).
3	INV-200 Port	Is used to interface the pulse inverter for door locks option.
4	Bypass/GPS Port	Is used for analog connection to some bypass units (check bypass list for compatibility and functionalities).

5	Pager Port	Is used to connect an optional AS-200P pager (to use this option, make sure to program pager option in Menu 3, Feature 5, Option 4).
---	-------------------	--


Entering Programming Mode

This allows the installer to program the unit. Once the system is in programming mode, the installer will have up to 20 seconds to select one of the sub-menus. If the installer fails to select a sub-menu before the 20-second delay, the system will exit programming mode and the installer will have to select again one of the 2 methods to get access to it.

Using the Hood Pin	Using the Antenna Programming Assistance Button (A.P.A.B.)
<ul style="list-style-type: none"> Press and hold the hood pin for 4 seconds. 	<ul style="list-style-type: none"> Make sure that the hood is closed.
<ul style="list-style-type: none"> Release the hood pin. The parking lights will turn ON. 	<ul style="list-style-type: none"> Turn the ignition key to the IGNITION ON (RUN) position.
<ul style="list-style-type: none"> While the parking lights are ON, press the hood pin once more and release immediately. The parking lights will turn ON and stay ON for 20 seconds. 	<ul style="list-style-type: none"> Within 5 seconds, press the programming button on the antenna twice for 1 second each time. The LED will come ON solid.
<ul style="list-style-type: none"> You now have 20 seconds to select one of the sub-menus. 	<ul style="list-style-type: none"> You now have 20 seconds to select one of the sub-menus.
<p>Note: To exit programming mode, close the hood.</p>	<p>Note: To exit programming mode, press on the antenna button once (the LED will come ON) and release.</p>

Remember: You can use the programming Assistance button instead of the hood pin at any time the hood is up.

The Programming Assistance Button (a.k.a. PAB)



The PAB is located on the side of the module. This push button mimics the hood-pin switch in order to avoid having to get out of the vehicle and pressing the hood-pin switch. **The PAB will work only when the hood is up.**

Once inside the programming options, the installer has a selection of many different sub-menus:

- a) Transmitter Programming
- b) Programming Options
- c) Honk Horn Timing* (*if available)
- d) Tach Programming

Manual or Automatic Transmission

This module may be installed on vehicles with manual or automatic transmissions. It is originally configured for manual transmissions. If the vehicle you are working on is automatic, it is mandatory to make a few quick and easy modifications before the unit is connected. **In the event that the**

configuration requires changes afterwards, a complete reset will be necessary before those changes become effective.

To install this unit in a vehicle with a manual transmission:

1. Make sure the **Yellow** loop on the PC board is connected.
2. Connect the **Black/White** handbrake wire located on the 12-pin harness to the vehicle handbrake switch.
3. Connect the **Violet (+)** door input **OR** the **Green (-)** door input wire located on the 12-pin harness to the vehicle door pin wire, which monitors all the doors of the vehicle (only use 1 of the 2 door trigger inputs).
4. Make sure the **Violet/White** TACH wire is plugged in – the TACH wire **MUST** be hooked up when the module is set for a manual transmission.
5. Make all your regular connections.
6. Power up the unit by first inserting the 5-pin connector, then the 6-pin connector and finally the 12-pin connector. The parking lights will flash **4 times** to confirm that the unit is in manual mode.
7. When learning the transmitter, the parking lights will flash **5 times** quickly, confirming that the module is set to manual mode.
8. **Upon the first successful remote start, the system will lock the transmission settings to manual mode.**

To install this unit in a vehicle with an automatic transmission:

1. Cut the loop on the pc board (**Yellow** wire).
2. Make sure the **Black/White** handbrake wire is not connected to any of the vehicle circuits.
3. Make all the regular connections.
4. Power up the unit. The parking lights will flash **4 times**.
5. When learning the first transmitter, the parking lights will flash **5 times** quickly then give **2 slow flashes**, confirming that the module is set to automatic mode.
6. **Upon the first successful remote start once the yellow loop has been cut, the system will lock the transmission settings to automatic mode.**

Note: If upon pressing the **START/STOP** button, the parking lights give **3 slow flashes**, make sure that the **Black/White** handbrake wire is not connected and that the yellow loop is cut and isolated.

Transmitter Programming Procedure

1. **Enter programming mode (see on page 15)** — the parking lights will stay on for up to 20 seconds.
2. Before the lights go out, turn the ignition key to the **OFF** position, then to **IGNITION ON (RUN)** and immediately back to the **OFF** position.
3. Press and hold the **LOCK** button and keep it down until the parking lights flash 5 times quickly.
4. The transmitter has been stored in memory.

Note: Each unit can store 4 remotes in its memory.

To program a transmitter on the second vehicle for multi-car operation, you must press the **TRUNK** button (instead of **LOCK** or **UNLOCK**) in step 3 of the transmitter programming procedure:

Entering Programming Options

1. **Enter programming mode (see on page 15)** — the parking lights will stay on for up to 20 seconds.
2. Before the lights go out, press and hold the brake pedal and then press one of the following buttons:

LOCKto access menu 1;
UNLOCK.....to access menu 2;
TRUNK..... to access menu 3; or

START/STOPto access menu 4.

3. The parking lights will flash and the horn will honk (if programmed) once, twice, three or four times to confirm entry into a menu.

4. Release the brake pedal.

Once the desired menu has been selected, the unit will fall (by default) into feature #1 of that menu; you can now select the option you want in feature 1. Once this option has been chosen, the unit will move on to feature 2 of the menu selected, and so on.

LOCK	for	Option 1,
UNLOCK	for	Option 2,
TRUNK	for	Option 3;
START/STOP	for	Option 4.

Programming Options

MENU 1

** indicates default setting*

FEATURE 1 – Ignition-controlled door locks

- OPTION 1*** Ignition lock **DISABLED**
- OPTION 2 Ignition lock **ENABLED**
- OPTION 3 Ignition unlock only
- OPTION 4 Ignition lock only

FEATURE 2 – Secure Lock

- OPTION 1*** Secure lock **DISABLED**
- OPTION 2 Standard secure lock **ENABLED**
- OPTION 3 Smart secure lock **ENABLED**

FEATURE 3 – Starter Kill arming mode

- OPTION 1*** Passive arming (60 sec.)
- OPTION 2 Active arming
- OPTION 3 Passive arming (3 min.)

FEATURE 4 – Door lock / unlock pulse timing

- OPTION 1*** 7/10-sec. lock / unlock pulses
- OPTION 2 4-sec. lock / unlock pulses
- OPTION 3 7/10-sec. lock pulse and two ¼ -sec. unlock pulses
- OPTION 4 1/10-sec. lock / unlock pulses

FEATURE 5 – LED flashing

- OPTION 1*** **ENABLED (without starter kill → will flash only when ignition is OFF)**
- OPTION 2 **DISABLED**
- OPTION 3 **ENABLED (with starter kill → will ONLY flash when the starter kill engages. This option should be selected ONLY if the starter kill is installed.)**

MENU 2

** indicates default setting*

FEATURE 1 – Safe Start

- OPTION 1 Safe Start **ENABLED**
- OPTION 2*** **Safe Start DISABLED**
- OPTION 3 "Swap Start" – enhanced safe start mode with extended safety:
To start the engine: press the **AUX** then **LOCK** buttons
To trigger **AUX 2**: press the **START/STOP** button. Must have configured option 1 or option 2 in menu 3 feature 3 (**AUX 2**).

FEATURE 2 – Engine Run Time

- OPTION 1 Run Time = 3 minutes in **gas mode** / 8 minutes **diesel mode**
- OPTION 2*** **Run Time = 15 minutes in gas mode / 20 minutes diesel mode**
- OPTION 3 Run Time = 25 minutes in **gas mode** / 30 minutes **diesel mode**

FEATURE 3 – Idle Mode & Turbo Mode (auto) / Turbo Mode (manual)

- OPTION 1 Idle mode & turbo mode **DISABLED (AUTO) / turbo mode DISABLED (MANUAL)**
- OPTION 2*** **Idle mode & turbo mode ENABLED (AUTO) / turbo mode DISABLED (MANUAL)**
- OPTION 3 Idle mode & turbo mode **ENABLED (AUTO) / turbo mode ENABLED (MANUAL)**

FEATURE 4 – Engine type and Cold Weather Mode

- OPTION 1 Diesel mode with 20-minute run time in cold weather mode (30-sec. wait to start delay)
- OPTION 2*** **Gas mode with 3-minute run time in cold weather mode**
- OPTION 3 Diesel mode with 8-minute run time in cold weather mode (18-sec. wait to start delay)
- OPTION 4 Diesel mode with 8-minute run time in cold weather mode (7-sec. wait to start delay)

FEATURE 5 – Ignition Valet

- OPTION 1 Ignition valet – **DISABLED**
- OPTION 2*** **Ignition valet – ENABLED**

MENU 3	<i>* indicates default setting</i>
FEATURE 1 – Home Valet	
OPTION 1	Home Valet ENABLED
OPTION 2*	Home Valet DISABLED
FEATURE 2 – AUX 1 Programming	
OPTION 1	Horn confirmation upon the 2 nd press of the LOCK button
OPTION 2*	Priority door access
OPTION 3	Horn confirmation upon the 1 st press of the LOCK button
FEATURE 3 – AUX 2 Programming	
OPTION 1	Constant output while pressing AUX followed by LOCK In safe start mode: activate AUX 2 by pressing the START/ STOP button
OPTION 2*	Toggle ON/OFF (with 30-second time out)
OPTION 3	Toggle ON/OFF (with 4-minute time out) → active when under remote run
OPTION 4	Priority door access
FEATURE 4 – AUX 3 / Zone 3 Programming	
OPTION 1	1-sec. output when TRUNK button is pressed for 3 sec. with ignition OFF or under remote run & data output (channel expander MCX-100 enabled)
OPTION 2*	Constant output while the TRUNK button is pressed
OPTION 3	Disarm/ream pulse with TRUNK & data output (channel expander MCX-100 enabled)
FEATURE 5 – External Trigger	
OPTION 1	Zone 3 disarm/ream (trunk pin: a disarm pulse is sent before the trunk opens; the vehicle rearms 4 seconds after the trunk is closed).
OPTION 2*	Key sense
OPTION 3	Engine start / stop
OPTION 4	Pager

MENU 4	<i>* indicates default setting</i>
FEATURE 1 – Multi-Level Features	
OPTION 1	Multi-car Features, Basic Features, Customized Features
OPTION 2*	Basic Features, Multi-car Features, Customized Features
OPTION 3	Customized Features, Multi-car Features, Basic Features
OPTION 4	Basic Features, Customized Features, Multi-car Features
FEATURE 2 – Alarm Control	
OPTION 1	ENABLED (HORN must be enabled in MENU 3 FEATURE 2, option 1 or 3)
OPTION 2*	DISABLED
FEATURE 3 – Ready Mode Option	
OPTION 1	Enabled by handbrake
OPTION 2*	Enabled by remote
FEATURE 4 – Bypass	
OPTION 1	ADS
OPTION 2*	Trilogix
OPTION 3	Fortin
FEATURE 5 – Bypass Type	
OPTION 1	One-Way communication
OPTION 2*	Two-Way communication

Virtual Tach System

* Virtual Tach System combines the latest microcontroller technology and a complex algorithm that took years to develop. VTS is able to effectively monitor the engine starting sequence and release the starter at the right time without physically connecting the tach wire to the remote starter. The VTS constantly monitors the data and readjusts itself automatically in order to maximize its capability to start the engine properly in any weather or deteriorating battery condition (*automatic transmission only*).

Optional Time Delay Adjustment in Virtual Tach System

Follow these steps to program crank time adjustment, if needed:


1. **Enter programming mode (see on page 15)** — the parking lights will stay on for up to 20 seconds.
2. Before the lights go out, press and hold the brake pedal and press the **LOCK** and **UNLOCK** buttons simultaneously — the parking lights will flash 4 times. **Do not release the brake pedal.**

3. Press the **LOCK** button if you wish to increase the time delay or the **UNLOCK** button if you want to decrease it. **The time delay will be increased or decreased by 50ms. and the parking lights will flash once every time the LOCK or UNLOCK button is pressed.**
4. Press the **TRUNK** button to save the settings you have entered.
5. Release the brake pedal – the time delay programming is now complete.

Multi-speed Tach Programming

1. **Enter programming mode (see on page 15)** — the parking lights will stay on for up to 20 seconds.
2. Before the lights go out, press and hold the brake pedal and press the **LOCK** and **UNLOCK** buttons simultaneously — the parking lights will flash 4 times. At that point, release the brake pedal.
3. Start up the engine and allow the vehicle to reach regular engine idle speed.
4. Once the engine is running at normal idle speed, press the brake pedal and keep it down until you hear the parking lights output click 5 times.
5. Release the brake pedal — the tach programming is now complete.

Other Features of the Module




Fifth Relay Output (2nd IGN, ACC or CRANK) Remote car starters of this series are equipped with an on-board high-current programmable 5th relay that can be used to power a second ignition, accessory or crank wire. The unit uses 3 sets of pins; each set corresponds to a specific function of the output. In order to activate one of the three possible functions, you must place the jumper (supplied) on one of the three sets of pins and connect the 14 AWG wire to the second **IGN. / ACC. / CRANK** wire of the vehicle.

Caution!

Only one set of pins can be used at one time. Using more than one jumper may result in serious damage to the vehicle. The relay output rating on this unit is 25a at most. Defective oem solenoid switches can sometimes draw up to 50 or 60a, causing the 30a fuse to blow. Always verify your circuit with an appropriate measuring device.

Tach jumper settings

Some new vehicles have a higher TACH voltage threshold, which would fall out of the normal TACH trigger circuit of the remote car starter. Changing the jumper to TACH Threshold HIGH will allow the module to properly detect the TACH signal.



Clutch Bypass

In order to remote start a manual transmission vehicle, the clutch switch must be bypassed. Clutch safety switch circuits can take many forms. Listed below are the most common ones. Some vehicles may also have a separate or combined switch on the clutch pedal for cruise control. Usually a cruise control switch reacts the moment you touch the pedal, whereas a clutch switch reacts only when the pedal is near the floor. Once the circuit type has been determined, you must recreate what happens electrically at the switch, with the remote start module, to bypass the clutch during remote starts. Relays are often used to accomplish this. Always use the Ground Out When Running (G.O.) as the negative trigger on your clutch bypass relays, as it is only active during remote starts. NEVER permanently bypass a clutch switch. Do not attempt this if you are unfamiliar with the use of relays and diode isolation.

Before any wiring attempts, test and record the way each wire tests in the following positions:

Without the pedal pressed:

- ◆ test the wire with the Ignition OFF
- ◆ test the wire with the Ignition ON
- ◆ test the wire with the Key in the start position

With the pedal pressed:

- ◆ test the wire with the Ignition OFF
- ◆ test the wire with the Ignition ON
- ◆ test the wire with the Key in the start position

With this information for every wire at the switch, determining what type of clutch switching system you have will be easy.

Direct Feed:

The simplest type of system to test and bypass is the "Direct Feed" system. This circuit simply interrupts the +12v signal starter wire from the ignition switch to the starter solenoid. There are 2 wires in this circuit, the "key side" wire which goes from the clutch pedal to the Ignition switch, and the "solenoid side" which goes from the clutch switch to the starter motor. When the key is turned to the start position without pressing the pedal, you will test 12v only on one of the wires at the clutch switch; this is the key side. When the pedal is pressed down and the key is in the crank position, the other wire will also read 12 volts; this is the solenoid side wire. Connect the starter output from the remote starter to solenoid side wire.

Note: In the next two systems a Relay in the vehicle interrupts the start wire between the Ignition switch and the starter motor. With the key in the start position and the clutch pedal pressed, the relay energizes and allows the start signal to reach the starter motor. In these systems a wires from the clutch triggers the relay when the pedal is pressed. There will be another wire at the clutch switch that supplies the signal to the trigger wire (either positive or negative, depending on the system).

Negative:

In a Negative system, when the clutch is pressed, a negative signal is sent to the relay. The relay energizes when the Key is turned to the start position. The 12volts from the start wire is allowed to pass through the relay and to the starter motor. One of the wires at the clutch will test as negative; this is the supply wire. The relay's negative trigger wire will only show negative when the pedal is pressed (some vehicles also require the Ignition system to be powered). If there is nothing else connected to the Ground Out When Running (G.O.) wire from the remote start module, the G.O. wire should be strong enough to trigger the vehicle's clutch relay. If there are other devices or

modules connected to the G.O. Wire, a relay (and diodes) may have to be added to strengthen the negative current going to the clutch bypass.

Positive:

Very similar to the negative system, except that the vehicle's clutch relay is triggered by 12 volts instead of a negative signal. In a Positive system, when the clutch is pressed; a positive (12 volts) signal is sent to the relay. The relay energizes when the Key is turned to the start position. The 12 volts from the start wire is allowed to pass through the relay and to the starter motor. One of the wires at the clutch will test as 12 volts; this is the supply wire. The relay's positive trigger wire will only show positive when the pedal is pressed (some vehicles also require the Ignition system to be powered). A relay is needed to send 12 volts to the trigger wire from the start module during start attempts.

Normally Closed (N/C):

Note: There are different types of this system used by various vehicle manufacturers; the following is used to illustrate how these systems work in general.

A Relay is also used in these types of systems to interrupt the starter wire. In the previous two examples, the clutch was bypassed by engaging the clutch relay; with this system you bypass the clutch by preventing the clutch relay from engaging. When the Ignition Key is turned to the start position the relay energizes and interrupts the start wire when the pedal is not pressed. When the Ignition key is turned to the start position and the pedal is pressed, the relay does not energize and the start signal reaches the starter motor.

In a N/C system the supply wire is connected to the relay's trigger wire at rest (pedal not pressed). When the pedal is pressed, the connection is broken between the supply wire and the relay's trigger wire (this disengages the relay). To verify that you have a N/C system, disconnect the clutch switch: the vehicle should start without the clutch pedal being pressed. When you test the trigger wire with your DMM meter, the trigger wire will test as 12 volts or negative when the pedal is not pressed. It should read as an open circuit (or Float) when the pedal is pressed.

Please note: Your probe may also show feedback from the other end of the circuit. The Polarity of the Trigger wire does not matter in this system, since all you need to do in order to bypass it is to use a relay to interrupt it during remote starts.

Installation-programmable Features

The following features can be programmed according to the needs of the installation and the requirements of the user:

Ignition-controlled Door Locks

This feature will **LOCK** all doors when the brake pedal is pressed while the ignition key is in the **IGNITION ON (RUN)** position. The unit will **UNLOCK** all doors when the ignition key is turned to the **OFF** position.

- If the **Ignition Lock Only** Option is selected, the system will only lock the doors.
- **Ignition Unlock Only** is selected; the system will only unlock the doors (provided the ignition key was in the **IGNITION ON (RUN)** position and that the brake pedal was pressed at least once).

Secure Lock

This feature allows the module to control certain OEM factory alarm systems without requiring the use of other wires for disarming the OEM alarm. (Namely, this feature is designed for OEM systems that use the factory lock wire to arm the alarm and the unlock wire to disarm it.)

➤ **Standard Secure Lock:**

If this Option is selected, upon receiving a remote start signal, secure lock will **unlock** the doors (disarming the factory Alarm); 1/2 second after the remote start, it will **relock** the doors. Four seconds after shutdown, secure lock will **relock** all doors (**arming** the system once again).

Please note that most OEM systems will **not** rearm the alarm while the engine is running, but **will** lock the doors.

➤ **Smart Secure Lock:**

If the vehicle was previously locked with the remote starter transmitter, at remote start the module will send an **unlock/disarm** pulse before start-up, **lock/arm** when the engine is running, and **lock/arm** once again 4 seconds after it shuts down the engine.

If the vehicle is initially unlocked, upon remote start the module will start the engine and arm the starter kill, but the doors will not be locked or unlocked at any moment of the sequence.

Starter Kill Arming Mode

The Starter Kill (if installed) can be configured by the installer either to **Passive Mode** (so as to arm automatically) or **Active Mode** (so as to require the user's intervention for arming). By default, the Remote Car Starter is configured to **Passive Mode**.

➤ **Passive mode:**

- To **arm** the Starter Kill, press the **LOCK** button on the transmitter, **OR**
- In Passive Mode, the Starter Kill will also automatically arm 1 minute (by default) or 3 minutes (if configured this way) after the ignition is turned **OFF** or once the last door is closed (if the doors are monitored).
 - **The LED on the antenna will flash quickly during the countdown preceding the activation of the Starter Kill.**
 - **Once the activation countdown expires, the LED will send a series of quick double flashes to indicate that the Starter Kill is now armed.**
- To **disarm** the Starter Kill, press the **UNLOCK** button on the transmitter.
 - **The Starter Kill will automatically rearm itself after 1 minute (by default) or 3 minutes (if configured this way) if no door is left opened (if the doors are monitored) and the ignition is not turned ON.**

➤ **Active Mode:**

- To **arm** the Starter Kill, press the **LOCK** button on the transmitter.
 - **The parking lights will flash once.**
 - **The LED on the antenna will flash slowly.**
 - **If remote door locks are installed, this will also lock the doors and arm the OEM-style alarm.**
- To **disarm** the Starter Kill, press the **UNLOCK** button on the transmitter.
 - **The parking lights will flash twice.**
 - **The LED on the antenna will remain OUT.**
 - **If remote door locks are installed, this will also unlock the doors.**

Lock Pulse Duration

- **Option 1:** 7/10-sec. **LOCK** and 7/10-sec. **UNLOCK** pulses by default.
- **Option 2:** 4-sec. **LOCK/UNLOCK** pulses.
- **Option 3:** A single 7/10-sec. **LOCK** pulse and two ¼-sec. **UNLOCK** pulses.
Used for double-pulse Disarm/Unlock systems
- **Option 4:** 1/10-sec. **LOCK** and 1/10-sec. **UNLOCK** pulses.

Flashing LED

To gain access to this feature, make sure the Flashing LED option has been enabled at the time of programming. Once this option is enabled, the user has the choice to toggle the Flashing LED **ON** and **OFF** at any given moment.

To toggle between the Flashing LED **ON** and **OFF**, press **LOCK** and **UNLOCK** simultaneously on the Transmitter. The parking lights will flash once slowly to indicate that the LED is active. If you press **LOCK** and **UNLOCK** once more, the parking lights will flash 3 times quickly to show that the LED is now disabled.

- **Flashing LED ON:** The LED will flash at all times (being passive or active arming) to denote that the Starter Kill is active.
 - **Active arming:** the LED flashes normally.
 - **Passive arming:** the LED will flash at a faster rate during the countdown until the Unit is armed, at which time the flashing rate will slow down.
 - **In Valet Mode:** the LED will be on solid.
- **Flashing LED OFF:** The LED will **not** flash when the module is armed (passive or active arming). However, if the module is in Valet Mode, the LED will remain on solid when the Ignition is **OFF**.

Safe Start

If this feature is enabled, the user must press the **START/STOP** button twice within 3 seconds to remote-start the vehicle. This will eliminate accidental remote starts, e.g. when children are playing with the transmitter.

- To remote-start the vehicle if **Swap Start Mode** is selected, press **AUX** and then **LOCK**.
- The **AUX 2** output can be activated by pressing the **START/STOP** button. The Option 1 or 2 must have been configured in Menu 3, Feature 3 (**AUX 2**).

Engine Run Time

On a gas engine, the Remote Car Starter can be programmed to run the engine for 3, 15, or 25 minutes (15 minutes by default). On a diesel engine, the Remote Car Starter can be programmed to run the engine for 8, 20, or 30 minutes (20 minutes by default).

Idle Mode

Convenience feature: Idle Mode allows the user to keep the engine running and the doors locked while they stop, for example, at a convenience store or for a short delivery.

This feature allows the user to let the remote starter take over control of the vehicle (i.e. no Key in the Ignition Switch) while the engine is running.

If the vehicle has an automatic transmission, proceed as follows to set the system to Idle Mode:

1. With the engine running, make sure to release the brake pedal and press the **LOCK**, **UNLOCK** or **START/STOP** button on the transmitter until the parking lights come **ON**.
2. Remove the ignition key from the ignition switch.
The engine will continue running.
3. Exit the vehicle and close all doors, hood and trunk.
4. Press the **LOCK** button to leave the doors locked.
This will also arm the OEM-style alarm and starter kill (if configured).
5. Press the **UNLOCK** button to leave the doors unlocked.

Note: The engine will continue running until the user re-enters the vehicle or until the expiration of the engine run time.

If the vehicle has a **manual transmission**, Idle Mode can be activated **through the same routine as that used for Ready Mode** (see “Ready Mode Option” in this Guide); at the last step, the **TRUNK** button is pressed instead of the other buttons.

Please note that the horn will honk once and that the OEM-style alarm will be armed if the Idle Mode option is enabled.

Note: If the pre-programmed run-time expires or if the user shuts down the engine by remote control, the vehicle will enter Ready Mode.

Caution!!! Do not leave children or pets unattended in a vehicle standing in Idle Mode.

Turbo Mode

If Turbo Mode is configured at installation, it will allow a turbocharger to idle down after the user leaves the vehicle: the unit will take over the vehicle and keep it running for 60 seconds (or until it is shut down by remote control), then shut down the engine.

If the vehicle has an automatic transmission, proceed as follows to set the system to Turbo Mode:

- 1) With the engine running, make sure to release the brake pedal and press the **LOCK, UNLOCK** or **START/STOP** button on the transmitter until the parking lights come **ON**.
- 2) Remove the ignition key from the ignition switch.
The engine will continue running.
- 3) Exit the vehicle and close all doors, hood and trunk.
- 4) **Press the TRUNK button; this will lock the doors, arm the OEM-style alarm (if configured) and confirm that the vehicle is in Turbo Mode.**
- 5) **The engine will shut down after 60 seconds.**

If the vehicle has a manual transmission, follow all steps of the Ready Mode routine (see “Ready Mode Option” in this Guide) to activate Turbo Mode. At the last step, press either:

- 1) **LOCK** to lock the doors and have the engine shut down after 60 seconds;
The parking lights will flash 3 times and remain lit.
The OEM-style alarm and starter kill (if configured) will be armed.
- 2) **UNLOCK** to unlock the doors and have the engine shut down after 60 seconds;
The parking lights will flash 3 times and remain lit.
- 3) **START/STOP** to shut down the engine without affecting the doors.

Note: The vehicle will enter Ready Mode once the engine run time expires.

Cold Weather Mode

If the vehicle has a **manual transmission**, Ready mode should be set before entering Cold Weather mode. When Cold Weather Mode is active, the engine starts every 2 hours and runs for 3 minutes (or for 8 or 20 minutes with diesel engines). Cold Weather Mode automatically ends after 24 hours (or 12 starts).

To enter Cold Weather Mode:

- Press and release the **AUX** button.
The LOCK button on the transmitter will light up.
- While the **LOCK** button is still lit up, press the **START/STOP** button.
The transmitter will beep once.
- Keep pressing the **START/STOP** button until the transmitter **beeps twice**.
- Release the **START/STOP** button.
Its LED will flash quickly.
The parking lights will flash 3 times.

To exit Cold Weather Mode, do any one of the following actions:

- Open the hood.

- Start the engine by remote.
- Turn the ignition key to the **IGNITION ON (RUN)** position.
- Press and release the **AUX** button.

The LOCK button on the transmitter will light up.

While the **LOCK** button is still lit up, press the **START/STOP** button.

The transmitter will beep once.

Keep pressing the **START/STOP** button until the transmitter **beeps once**

Release the **START/STOP** button.

Its LED will flash quickly.

The parking lights will flash once.

To verify whether the system is in Cold Weather Mode (automatic transmissions only):

- Press the brake pedal:
- If the vehicle is in cold weather mode, the parking lights will stay on while the pedal is pressed.

Valet Mode

When the vehicle is in Valet Mode, the remote starter and alarm (if configured) functionalities are disabled. If the vehicle needs to be serviced, or if you park it indoors, the Valet Mode will prevent the engine from being remote-started accidentally.

➤ Any of the following features will put your remote car starter into Valet Mode:

- **Ignition Valet:** This feature allows you to put your system into Valet Mode by using the **ignition key**.
- **Remote valet:** This feature allows you to put your system into Valet Mode by using the **transmitter**.
- **Valet switch:** This feature allows you to put your system into Valet Mode by using a **push button switch (optional)**.

To put the system i n t o Valet Mode

• To put the system i n t o Valet mode using the KEY (Ignition Valet Mode):

- Insert the ignition key into the ignition switch. Within 10 sec., turn the key 5 times successively into the **IGNITION/RUN** and **OFF** positions.

The parking lights will flash three times.

- Turn the ignition **OFF**

The LED on the antenna will come ON solid to indicate that the vehicle has successfully entered Valet mode.

• To put the system i n t o Valet mode using the TRANSMITTER (Remote Valet Mode):

- Press the **UNLOCK** and **START/STOP** buttons simultaneously until the parking lights flash **three times**.

The LED on the antenna will come ON solid to indicate that the vehicle has successfully entered Valet mode.

• To put the system i n t o Valet mode using the PUSH BUTTON SWITCH (Valet Switch Mode):

- Insert the ignition key into the ignition switch.
- Turn the key into the **ON** position
- Within 5 seconds, press the push button switch until the parking lights flash **3 times**.
- Release the push button and turn the ignition to the **OFF** position.

The LED on the antenna will come ON solid to indicate that the vehicle has successfully entered Valet mode.

To put the system o u t o f Valet Mode

• To put the system o u t o f Valet mode using the KEY (Ignition Valet Mode):

- Insert the ignition key into the ignition switch. Within 10 sec., turn the key 5 times

successively into the **IGNITION/RUN** and **OFF** positions.

The parking lights will flash twice.

- b. Turn the ignition **OFF**

The LED on the antenna will flash quickly to indicate that the vehicle is now out of Valet mode.

- **To put the system out of Valet mode using the TRANSMITTER (Remote Valet Mode):**

- a. Press the **UNLOCK** and **START/STOP** buttons simultaneously until the parking lights flash **twice**.

The LED on the antenna will flash quickly to indicate that the vehicle is now out of Valet mode.

- **To put the system out of Valet mode using the PUSH BUTTON SWITCH (Valet Switch Mode):**

- a. Insert the ignition key into the ignition switch.

- b. Turn the key into the **ON** position

- c. Press the push button switch until the Parking lights flash **twice**.

- d. Release the push button and turn the ignition to the **OFF** position.

The LED on the antenna will flash quickly to indicate that the vehicle is now out of Valet mode.

“Home Valet™” Mode

If configured at installation, this feature will set the vehicle to a no-remote-start mode: if the vehicle is parked indoors, there is no danger of it starting accidentally by remote control.

Note: Once the home valet mode is activated, the vehicle will not start by remote but the OEM alarm functions and starter kill will still be enabled.

To take the system into home valet mode:

- Press the **LOCK** or **UNLOCK** button.

- Within 3 seconds, press the **START/STOP** and **LOCK** buttons simultaneously.

The parking lights will come ON for 2 seconds, then turn OFF.

To take the system out of home valet mode:

- Turn the ignition key to the **IGNITION ON (RUN)** position.

The system will warn the user if someone attempts to start the vehicle while it stands in Home Valet Mode:

- The parking lights will:
 - Turn **ON** then **OFF**; then
 - Flash **twice**, pause; then
 - Flash **twice** again.

Panic Mode

Note: Panic mode can only be activated if the horn has been adequately configured.

In an emergency situation, you can activate panic mode by pressing and holding the **START/STOP** button for more than 3 seconds, until the horn starts honking. If the vehicle is under a remote start, the engine will shutdown automatically before setting off the horn. You can stop the horn by pressing:



(this will lock your doors and deactivate panic mode), or



(this will unlock your doors and deactivate panic mode).

Furthermore, the panic mode can be stopped by activating one of the following three (3) features:

- a) Remote valet (pressing **UNLOCK** and **START/STOP** for at least 3 seconds)

- b) Ignition valet (turning the key inside the ignition switch from **OFF** to **ON** 6 times in a row)

- c) By turning the key to the **ON** position and pressing the valet switch (if included) until the parking lights flash 5 times.

Panic Mode will automatically shut down after 30 sec.

The AUX 1 / 2nd Unlock

(Both AUX 1 and AUX 2 can be programmed for Priority Door Access.) This great feature allows the user to unlock solely the driver's door with a single press of the **UNLOCK** button on the transmitter, and to unlock the other doors, if desired, by pressing the **UNLOCK** button for a second time.

The output will provide a 1-second negative output when the **UNLOCK** button is pressed a second time on the transmitter. This can be used not only as **priority door access**, but also as trunk release.

➤ Horn Confirmation:

AUX 1 can be programmed to trigger the horn every time the **LOCK** button is pressed, or when the **LOCK** button is pressed twice within 3 seconds. When horn confirmation is activated, panic mode is enabled. If horn confirmation is disabled, panic mode will not be available.

The AUX 2 Timed Output

This 500 mA negative **AUX 2** output can be used for many different applications. It can be programmed for priority door access if **AUX 1** is programmed for horn confirmation. For additional information, please refer to the "**3-pin Harness**" section earlier in this Guide.

The AUX 3 / Trunk or Sunroof Output

This 500 mA negative **AUX 3** output can be used for many different applications. The output can be programmed to give a 1-second pulse when the **TRUNK** button is pressed (if the ignition is **OFF** or during a remote start), or to give a continuous output as long as the **TRUNK** button is held down (for sunroof or window control).

If the **Option 3** is selected, a disarm pulse will be sent before the trunk is popped. An arm pulse will be sent 4 seconds later. This option is overridden when the **Zone 3 option** is used as a trunk pin (Menu 3, Feature 5, Option 1).

Programmable External Trigger

For additional information, please refer to the "**12-pin Accessories Harness**" section earlier in this Guide.

Multi-Level Features (*default state*)

The multi-level features allow the user to access different features of the vehicle or of a second car by pressing the **AUX** button once, twice or three times. By default, the multi-level features are programmed as follows:

Basic features (*press the AUX button 1X*)

AUX	➤	LOCK:.....	aux 2
AUX	➤	TRUNK:	status request
AUX	➤	START/STOP	cold weather

Multi-car operation (*press the AUX button 2X*)

AUX	➤	AUX	➤	LOCK:	2 nd car lock
AUX	➤	AUX	➤	UNLOCK:	2 nd car unlock
AUX	➤	AUX	➤	START/STOP:	2 nd car start/stop
AUX	➤	AUX	➤	TRUNK:	2 nd car trunk

Customized features (*press the AUX button 3X*)

(May not be applicable for certain vehicles)

You can add customized features such as turning on the radio, opening sliding doors, etc.

Please note that the **MCX-100 channel expander** is required in order to add customized features. The **Option 1 or 3 in Mode 3, Function 4** must also be selected.

AUX	➤	AUX	➤	AUX	➤	LOCK:	customized feature 1
AUX	➤	AUX	➤	AUX	➤	UNLOCK:	customized feature 2
AUX	➤	AUX	➤	AUX	➤	TRUNK:	customized feature 3
AUX	➤	AUX	➤	AUX	➤	START/STOP:	customized feature 4

You can customize the system as to personalize these multi-level features in an order that best suits the user. Your options are:

Option 1:

Level 1 (requires pressing the AUX button 1X)	→	Multi car operation
Level 2 (requires pressing the AUX button 2X)	→	Basic features
Level 3 (requires pressing the AUX button 3X)	→	Customized features

Option 2:

Level 1 (requires pressing the AUX button 1X)	→	Basic features
Level 2 (requires pressing the AUX button 2X)	→	Multi car operation
Level 3 (requires pressing the AUX button 3X)	→	Customized features

Option 3:

Level 1 (requires pressing the AUX button 1X)	→	Customized features
Level 2 (requires pressing the AUX button 2X)	→	Multi car operation
Level 3 (requires pressing the AUX button 3X)	→	Basic features

Option 4:

Level 1 (requires pressing the AUX button 1X)	→	Basic features
Level 2 (requires pressing the AUX button 2X)	→	Customized features
Level 3 (requires pressing the AUX button 3X)	→	Multi car operation

Example: If the multi-level features have been modified from their default state to option 3, the setup would be as follows:

For “**Basic features**”:

- To access the **AUX 2** feature, the user needs to press on the **AUX** button **three (3)** times followed by the **LOCK** button.
- To access the **status request** feature, the user needs to press on the **AUX** button **three (3)** times followed by the **TRUNK** button.
- To access **cold weather mode**, the user needs to press on the **AUX** button **three (3)** times followed by the **START/STOP** button.

OEM-Style Alarm

The OEM-style alarm (if configured) monitors the doors, hood and ignition switch of the vehicle. It will sound the horn if a door or the hood is opened, or if the key is turned in the ignition (**the horn option must be enabled and one of the door inputs must be connected**).

- To **arm** the OEM-style alarm, press the **LOCK** button on the transmitter.
 - **The OEM-style alarm will ONLY arm if the LOCK button on the transmitter is pressed.**
 - **The LED on the antenna will flash slowly to indicate that the OEM-style alarm is now armed.**
- To **disarm** the OEM-style alarm, press the **UNLOCK** button on the transmitter.
 - **To stop the horn from sounding if the OEM-style alarm is triggered, press the LOCK or UNLOCK button, or put the system in and out of Valet Mode.**

Ready Mode Option

If the vehicle has a **manual transmission**, please read the following indications. In order to start the vehicle by remote, the unit must first be set to Ready Mode. If the unit is not set to Ready Mode, it cannot remote start the vehicle.

Please note that Ready Mode can be enabled by the remote or the handbrake, depending on the option that was selected. Therefore, you must follow the appropriate procedure between the two described below in order to set the vehicle into Ready Mode.

Once the system is set to Ready Mode, the vehicle can be remote started and stopped at any time. The system will exit Ready Mode if a door, the hood or the trunk is opened, if the brake pedal is pressed, if the parking brake is disengaged or if the ignition key is turned to the **IGNITION ON (RUN)** position.

To set the system to Ready Mode:

If Ready Mode is enabled by remote	If Ready Mode is enabled by handbrake
1. Ensure that all the doors, hood and trunk are closed. Make sure that the gear selector is in the neutral position.	
2. With the engine already running, apply the parking brake once and release the brake pedal. Make sure to release the brake pedal.	2. With the engine already running, apply the parking brake twice and release the brake pedal. Make sure to release the brake pedal. The parking lights will flash 3 times quickly and remain lit. Skip to step 4.
3. Within 20 sec. of engaging the parking brake, press and hold LOCK, UNLOCK or START/STOP on the transmitter. The parking lights will flash 3 times quickly and remain lit.	-
4. Remove the key: the engine will continue running.	
5. Exit the vehicle and close all doors, hood and trunk.	
6. Press for approx. 1 second either: <ul style="list-style-type: none">a. LOCK to lock the doors and shut down the engine;b. UNLOCK to unlock the doors and shut down the engine;c. START/STOP to shut down the engine without affecting the doors.	

Note: The vehicle will also enter Ready Mode once the engine run time expires.

Bypass

Remote starters of this series offer three possibilities for bypass D2D: they are compatible with Trilogix, ADS and Fortin bypasses (**Trilogix by default**).

Vehicle Status Request

The status request feature allows the user to see the status of the vehicle —i.e.: if the doors are locked or unlocked or if the vehicle is in cold weather mode, home valet mode, valet mode or how much time is left in the run time cycle. The following charts (Tables 1, 2 and 3) indicate the confirmation sequences.

To retrieve the vehicle status:

Press and release the **AUX** button then press and release the **TRUNK** button (there will be a beep). The transmitter will then flash the corresponding sequence of LEDs, depending on the vehicle's status.

- **If the engine is NOT running**, refer to Table 1.
- **If the vehicle is in or out of ready mode**, refer to Table 2.
- **If the engine IS running under a remote start**, refer to Table 3.

The status request feature is a two-step procedure:

- The first sequence of flashes denotes if the vehicle's doors are locked or unlocked.
- The second sequence of flashes (if applicable) denotes if the vehicle is in *Cold weather mode*, *Home valet mode*, or *Valet mode*.
- If there is no second-sequence transmission, then the vehicle is in none of the three (3) mentioned features (*Cold weather mode*, *Home valet mode* or *Valet mode*).

Status Request When the Engine IS NOT Running

STATUS	SEQUENCE	LED #1	LED #2	LED #3	LED #4	Beep(s)
Lock		3 flashes	X	X	X	1
Unlock		X	3 flashes	X	X	2
Cold Weather	1 st sequence if locked	3 flashes	X	X	X	2
	1 st sequence if unlocked	X	3 flashes	X	X	2
	2 nd sequence	X	X	X	1 second	X
Home Valet	1 st sequence if locked	3 flashes	X	X	X	2
	1 st sequence if unlocked	X	3 flashes	X	X	2
	2 nd sequence	1 second	X	X	1 second	X
Valet Mode	1 st sequence if locked	3 flashes	X	X	X	1
	1 st sequence if unlocked	X	3 flashes	X	X	1
	2 nd sequence	1 second	X	X	1 second	X

Table 1

Ready Mode Status Request

STATUS	SEQUENCE	LED #1	LED #2	LED #3	LED #4	Beep(s)
In Ready Mode	if locked	3 flashes	X	X	X	1
	if unlocked	X	3 flashes	X	X	2
Out of Ready Mode	1 st sequence if locked	3 flashes	X	X	X	1

STATUS	SEQUENCE	LED #1	LED #2	LED #3	LED #4	Beep(s)
	1 st sequence if unlocked	X	3 flashes	X	X	2
	2 nd sequence	X	X	X	4	4

Table 2

Status Request When the Engine is Running

When the vehicle doors are locked:

The LED # 1 will flash 3 times to denote that the vehicle's doors are locked.

When the vehicle doors are unlocked:

The LED # 2 will flash 3 times to denote that the vehicle's doors are unlocked.

RUN TIME	Beep(s)	LED #1	LED #2	LED #3	LED #4
If there is more than 3/4 of run time cycle	3	ON for 1-sec	ON for 1-sec	ON for 1-sec	ON for 1-sec
If there is more than half of run time cycle	3	ON for 1-sec	ON for 1-sec	ON for 1-sec	X
If there is more than 1/4 of run time cycle	3	ON for 1-sec	ON for 1-sec	X	X
If there is less than 1/4 of run time cycle	3	ON for 1-sec	X	X	X

Table 3

Multi-car Operation

This option allows the owner of two vehicles, both equipped with the same Remote Car Starter model, to control both systems with a single remote control. To control the second vehicle, simultaneously press the **TRUNK** button and the button of the function you wish to use.

Note: The remote control must be configured for second car operation by the installer.

To control the second vehicle:

Press **TRUNK + LOCK** buttons simultaneously: **LOCK**

Press **TRUNK + UNLOCK** simultaneously: **UNLOCK**

Press **TRUNK + START/STOP** simultaneously: **START**

Press **TRUNK + START/STOP** simultaneously: **STOP**

or

Press **AUX > AUX > LOCK**: **LOCK**

Press **AUX > AUX > UNLOCK**: **UNLOCK**

Press **AUX > AUX > START/STOP**: **START**

Press **AUX > AUX > START/STOP**: **STOP**

Press **AUX > AUX > TRUNK**: **TRUNK**

Note: If the multi-level features have been modified from their default state, the **AUX** button may have to be pressed once, twice or three times, according to the option you chose.

Horn Honk Timing

Follow these steps to program horn confirmation:

1. **Enter programming mode (see on page 15)** — the parking lights will stay on for up to 20 seconds
2. Press and hold the brake pedal, then simultaneously press the **UNLOCK** and **START/STOP** buttons — the horn will chirp 5 times.
3. Release the brake pedal.
4. To change the timing:
 - a. To increase the Horn pulse by 3 ms, press the **LOCK** button.
 - b. To decrease the pulse by 3 ms, press the **UNLOCK** button.
 - c. To increase the pulse by 10 ms, press the **START/STOP** button.
 - d. To decrease the pulse by 10 ms, press the **TRUNK** button.
5. To save the new settings: press **LOCK** and **UNLOCK**. If 3 chirps are returned, the new settings have been saved

Resetting the module to default features

Resetting the module is not a required process. Most of the time, you can avoid resetting the module by fixing the issue directly at the root of the cause.

To reset the module:

1. Enter programming mode.
2. In 10 seconds or less, press the brake pedal 6 times.
3. The parking lights will flash 8 times, confirming the reset.

On some vehicles such as BMWs and certain Volkswagens, pressing the brake pedal without the key in the ignition **ON** position will not work. If this is the case, simply leave the ignition **ON** while performing the reset.

Closing Up

- Use tie-wraps or screws to properly secure the starter module and keep the wiring away from any moving parts such as the parking brakes or steering column shafts. Mount all switches in good and accessible locations where they do not risk getting kicked or hit accidentally.
- Most comebacks are the result of misunderstandings about how a product works or performs. Take the time to properly explain all functions and features to the customers before they leave the premises. Doing this will save time and money.
- Always make all your connections before plugging in the module, and be sure to test all functions properly before closing up the installation.
- Show the customer where the optional valet switch has been installed and place the warning label in a visible location under the hood.

Testing

Before putting back the vehicle together, it is recommended to check that the system operates properly. The following testing procedures should be used to verify proper installation and operation of the system. Before testing, make sure that all connections are soldered and that the unit is plugged in.

- If installed on a MANUAL transmission, make sure the system properly enters and exits ready mode (see earlier in this Guide).**
- Remote-start the engine and listen for starter drag.** If the starter cranks for too long, carry out another tach programming procedure.

- ❑ **Hood switch shutdown.** With the vehicle running under the remote car starter, open the hood; the vehicle should shut down. If it does not shut down, check the hood pin-switch and its connector.
- ❑ **Brakes shutdown circuit.** With the vehicle running under the remote car starter, press and release the brake pedal. The engine should shut down immediately. If the engine continues to run, check the brakes switch connection.
- ❑ **OEM alarm control.** Make sure the module is able to arm and disarm the oem alarm (if applicable).
- ❑ **Door locks and trunk testing.** Make sure each of these options respond to the transmitter (if installed).
- ❑ **Starter kill option.** Sit inside the vehicle with all doors closed. Arm the vehicle, then try to start the engine with the key. The engine should not start. If the engine starts, rewire the starter kill to reach proper operation.
- ❑ **Valet mode.** Make sure the remote car starter is able to properly enter and exit valet mode. When setting the remote car starter into valet mode, pressing the lock button will lock the doors without activating the starter kill. (Refer to the user guide for further information on valet mode.)
- ❑ **Idle mode.** Make sure the vehicle properly enters and exits idle mode.

Troubleshooting Poor Transmitting Range

Many factors may affect the operating range of the transmitter. Some of these are:

- The condition of the battery in the transmitter.
- The operating environment (for example: downtown radio-frequency noise, airports, cellular phone towers...).
- Metal: any type of metal will affect operating range. This includes the vehicle itself.
- The shape of the vehicle can affect range as well (vans in general have less range).
- The shape of the roof and A-pillars brings about considerable radio-frequency deflection (in this case, the signal from the remote control). As a result, the direction in which the vehicle is facing in relation to the remote control can affect the range. Straight on (standing in front of the vehicle) generally gives you the greatest range; the second best performance is from the back. Using the remote control from either side of the vehicle will usually give the lowest range.
- The range will be significantly lower in a crowded parking lot than in open space.
- Always hold the transmitter high, approximately at shoulder height.
- The operating range will be somewhat lower on vehicles equipped with an aftermarket or factory alarm.

Diagnostics – Parking Light Flash Table

Flashes	Description	
1	<ul style="list-style-type: none"> • Doors locked, starter kill armed. • Run time has expired. • TRUNK button pressed. 	<ul style="list-style-type: none"> • Start signal received by the module. • Cold weather mode cancelled.
2	<ul style="list-style-type: none"> • Doors unlocked, starter kill disarmed. • Remote start attempt cancelled by remote. • Exiting ignition valet. • Exiting remote valet. 	<ul style="list-style-type: none"> • Power-up reset. • Board set from manual to automatic; power ON. • Power ON to OFF (automatic transmission).
2 slow flashes then 8 quick flashes	<ul style="list-style-type: none"> • Reset from Manual to Automatic 	
3	<ul style="list-style-type: none"> • Entering cold weather mode. • Extended run time. 	<ul style="list-style-type: none"> • Entering ignition valet. • Entering remote valet.
3 Slow (automatic transm.)	<ul style="list-style-type: none"> • Parking brake is engaged 	<ul style="list-style-type: none"> • Yellow loop has been reconnected
4	<ul style="list-style-type: none"> • +12 V detected on the brake input wire either while cranking or during run time. • Entering multi-speed tach programming. <ul style="list-style-type: none"> • Entering time delay adjustment in virtual tach system • Board set from automatic to manual; power ON. • Power ON to OFF (manual transmission). 	
5 Fast	<ul style="list-style-type: none"> • Tach signal programmed. • New transmitter programmed 	
6	<ul style="list-style-type: none"> • A remote start was attempted while a tach-before-crank signal was detected before cranking. 	
8	<ul style="list-style-type: none"> • Unit reset; see "Resetting the Module". 	
10	<ul style="list-style-type: none"> • A ground (-) signal was detected on the hood pin input wire. 	
1 – pause – 2	<ul style="list-style-type: none"> • There was a remote start attempt while the vehicle was in valet mode. • Failed start: vehicle's low battery voltage. 	
ON SOLID for 3 seconds....	...followed by 1 flash	Exiting cold weather mode
	...followed by 3 flashes	Entering cold weather mode
ON continuously	<ul style="list-style-type: none"> • Idle mode: Idle mode is engaged • Run time: The vehicle has been remote started and is in run time. 	
ON 2 seconds	<ul style="list-style-type: none"> • The hood has been opened and a ground (-) signal has been detected on the hood pin input wire. 	
ON 4 seconds	<ul style="list-style-type: none"> • Locking or unlocking a door (with Door pulses configured to 4 sec.) 	
ON 20 seconds	<ul style="list-style-type: none"> • The hood pin has been flashed and you are now in the programming centre. 	
Continuous flashes 25 seconds	<ul style="list-style-type: none"> • Panic mode is activated. 	
Continuous flashes 60 seconds	<ul style="list-style-type: none"> • OEM alarm triggered (Honk) 	

Troubleshooting Q & A

The following are some common installation-related issues.

A problem or symptom is given and then possible solutions and/or suggestions as to areas to verify are enumerated.

1. **I cannot program the remote control.**

- Do the parking lights come on when you open the hood? (Does the hood pin work?)
- Is the antenna plugged in?
- Does the light on the remote control turn on when you press the button?
- Is the ignition wire connected properly?
- Are you waiting too long between programming steps?
 - After flashing the hood pin and turning the key to **ON**, **WAIT** for 2 seconds.
 - Turn the key **OFF**, **ON**, **OFF**, then keep pressing the **LOCK** button repeatedly until you get 5 light flashes from the module.

The entire process should take less than 20 seconds.

2. **The car will not start by remote.**

- Does the light on the remote light up when you press the button?
- Is the starter in valet mode?
- Does the vehicle have passive antitheft security (PATS, VATS, PASSLOCK, TRANSPONDER)?

3. **The starter motor cranks for 8 seconds but the car will not start.**

- Are you on the correct ignition wire?
- Does the car have more than 1 ignition?

4. **The car cranks briefly then quits.**

- Have you bypassed the passive security (PASSLOCK, PASSKEY III, PATS...)?
- Have you adjusted tach?
- Is the vehicle's battery weak?

5. **The parking lights come on for 8 seconds but the starter motor will not crank.**

- Does the car have an aftermarket starter kill?
- Have you bypassed the VATS or Passlock II?
- Is the start wire hooked up correctly?
- Has the clutch been bypassed properly (for standard transmissions)?

6. **The car starts but starter stays engaged.**

- Make sure ignition and crank are not common with the key out (connected at rest). May have to add relay (i.e. Tercel, Altima).
- Did you make an auto tach adjustment?
- Weak tach signal?
- Bad ground?

7. **The car starts by remote but then the starter re-engages.**

- Check ground wire.
- Is tach programmed?

8. **The car starts on its own.**

- Is the module in cold weather mode?
- Program remote 4 times (another remote may be programmed to your module).
- Is external trigger shorting out to ground?

9. **I get one long flash when I press the button trying to go into ready mode.**

- Check tach circuit.

10. **The factory alarm goes off when I start by remote.**

- Did you hook up the disarm wire?

- Do you have the correct OEM disarm wire?
 - Did you program the disarm wire?
11. **The ABS and the CHECK ENGINE light come on in the dash.**
 - Are you missing a second ignition or accessory?
 12. **The car starts and runs but the heater blower motor does not work.**
 - Incorrect accessory wire.
 - Does it have more than one accessory?
 13. **The car starts, the heater works but the air conditioning system does not.**
 - Missing second accessory (common on some Fords).
 14. **The CHECK ENGINE light comes on and the vehicle does not shift; it feels sluggish.**
 - Missing second ignition (common on some GMs).
 15. **On cold mornings the parking lights come on, go out, and then flash twice slowly.**
 - Check for a weak car battery (try using the cold weather mode option).
 16. **The car does not start and the parking lights flash 4 times.**
 - Check brake circuit.
 - Check for blown rear parking light (feedback).
 17. **The vehicle runs for 8 seconds then shuts down. I have 12 volts on starter wire the whole time but no over crank.**
 - Did you make an auto tach adjustment (new GM trucks, cars and mini vans)?
 18. **The car runs for about 5 seconds, shuts down and restarts; it does this 3 times.**
 - Check voltage on tach wire.
 - Try an alternate tach source.
 19. **The car starts by remote but the range is poor.**
 - Is the car tinted?
 - Does it have an aftermarket alarm?
 - Is the antenna mounted below the tint strip?
 - Using the correct remote?
 - Change remote battery.
 - Heated front windshield (Taurus, Crown Victoria)?
 - Metal film in windshield (GM Mini vans)?
 20. **I get excellent range when the vehicle is not running but almost none when it is running.**
 - Check for loose spark plug boot or faulty ignition wires, cracked cap.
 - Try disconnecting blower motor.
 21. **The radio stays on after the vehicle shuts down.**
 - Retained Accessory Power will keep power to radio for approximately 10 - 15 minutes or until it sees a door open (Fords, GM's R.A.P.).
 22. **The headlights stay on after the car shuts down by remote.**
 - Switch headlight switch from auto to normal (Toyotas).
 - On some vehicles, opening a door will shut the headlights off. Pulse the driver's door pin with the rearm wire.
 23. **I get no 12v reading at all at the brake pedal, depressed or not.**
 - Some vehicles require the ignition be on (BMW).
 24. **The parking lights flash on their own.**
 - Check hood pin adjustment.
 - Bad ground?

25. **I blow fuses every time I try the remote door locks and I have already installed a relay.**
 - Door locks are reverse polarity, and not positive trigger.
26. **I blow fuses every time I try the remote trunk release and I have already installed a relay.**
 - Trunk release is reverse polarity, and not positive trigger.